

# Hammock Chair



## Parts List


- (1) Hammoka Chair with Footrest, Cup Holder & Carrying Case
- (1) 3/16" Center Dowel
- (1) 19" Footrest Dowel
- (2) 30" Armrest Dowels
- (1) Large S-Hooks
- (1) Small S-Hook
- (1) Eye Lag Screw

Make sure all of the above pieces are included prior to hanging your Hammoka Chair. If anything is missing, please contact customer service at [www.hammocks.com](http://www.hammocks.com) or 1-888-577-1529.

## Step 1: INSTALLING THE EYE LAG SCREW

*(skip this step if you are installing on a Hammoka Stand)*

1. Locate the ceiling joist or beam using a stud finder or similar tool. For your safety, be sure to locate the exact center of the joist.
2. Using a 3/16" wood drill bit, drill a hole (approximately 5" deep) perpendicular to the ceiling. THE HOLE MUST BE DIRECTLY IN THE CENTER OF THE STUD/JOIST FOR MAXIMUM WEIGHT BEARING CAPACITY (see fig.1). Failure to do so could cause loosening in the eyebolt.
3. Screw the included eye lag screw into hole until all threads have disappeared into the beam/joist.
4. Make sure the eyebolt is securely placed into the beam/joist each time before sitting in the chair. Failure to do so could result in injury. Do not loosen or adjust the eye lag once it is in place.



## Step 2: HANGING THE HAMMOCK CHAIR


1. Hang the chair from the installed eye lag by tying the ropes to the large S-hook.
2. Align the two rope ends and pass them through the smaller part of the large S-hook.
3. Knot the rope as shown in the illustration (see fig. 3). Pull knot tightly.
4. Wrap any excess rope around the knot.

## Step 3: INSTALLING DOWELS (see next page for dowel placement)

*(Dowel pocket holders will be snug - please fit dowel in firmly)*

**CAUTION:** Pulling or putting pressure directly on the dowel in any way could result in injury and/or breaking of the dowels. Please DO NOT pull on any of the dowels.

1. Take large dowel (36") and place each side firmly into the black dowel pocket holders at the top of the chair (see fig. #4).
2. Take the two medium dowels (30") and place each into the black dowel pockets above the right and left armrests.
3. Firmly press each dowel into the side black dowel pocket holders.



## Step 4: HANGING THE FOOTREST

1. Take the footrest rope and slide it through the small S-Hook.
2. Tie a secure knot (see fig. 3).
3. Attach small S-Hook onto large S-Hook in ceiling joist.
4. The footrest may be adjusted up and down for comfort.
5. Take the small dowel (19") and fit firmly into each side of black dowel pocket holders.


## Step 5: HANGING THE CUP HOLDER

1. Wrap cup holder strap around large dowel (see fig. #5).
2. Slide cup holder through opening and pull tight to secure cup holder.

## Step 6: INFLATING THE HEADREST

1. Open and pinch valve to allow for air passage. Inflate to your desired firmness and close valve securely to avoid deflation.

**CLEANING YOUR CHAIR** - To wash, simply scrub with a soft brush using warm, soapy water and hang to dry. Do not use a washing machine, a tumble dryer, or any chemical bleaches/cleaners.



**CAUTION!** The Hammoka Hammock Chair is not designed as a swing. Bouncing, swinging, or any other significant movement while in the chair may cause serious injury or death. **Weight limit 350 lbs.**

# Hammock Chair

---

